


ASSEMBLY INSTRUCTIONS

SKU# DJ1290BK-56CM



⚠ SAFETY TIPS:

Static charge may cause dust on foam-clean with a dry or damp cloth. Small foam strands may be present-handle gently and dispose of properly. Do not burn or incinerate. Check local recycling guideline.

Installation Video QR



DJ1290

<https://vimeo.com/1040299034>

Have an assembly question or need a replacement part?
Please contact with our customer service.

Warnings

To reduce the risk of injury, read and follow all of the warnings, precautions, and instructions in this manual before you use the equipment. Warnings and instructions for care, maintenance, and use of this equipment are included to promote safe enjoyable use of this equipment.


⚠ WARNING

- Any use of this product other than that intended may lead to serious injury.
- Prior to use, read the instructions carefully and comply with all warnings and instructions.
- Do not let children use this appliance, keep children and pets away from it. Teenagers must be supervised.
- You must replace the sticker if it is damaged, illegible or missing.
- Keep your body, clothing, and hair free and clear of all moving parts. Tie long hair back so that it does not get in the way when exercising.
- Not suitable for therapeutic purposes.
- Do not exceed weight capacity.
- Always use the security devices.
- It is the responsibility of the owner to ensure that all users of the weight training system are adequately informed of all precautions.
- Always consult a physician before beginning any exercise program. This is especially important if you are over 35 or have experienced health problems before.
- Always wear sports shoes for foot protection while using the weight training system.
- Before each use, make sure your product is locked (pins engaged). Inspect and properly tighten all parts and replace any worn parts immediately.
- Users are responsible for maintaining the product in good condition after setting it up and before each use.
- This product is intended for home use only. Do not use the product in a commercial, rental or institutional environment.
- The equipment must be placed on a flat, stable surface.
- Leave enough space around the apparatus in order to exercise in complete safety.
- For your own safety, regularly inspect your product.
- Remove any jewellery that you're wearing.
- Over exercising may result in serious injury or death. If you experience dizziness, nausea, chest pain or any other abnormal symptoms, immediately stop your workout and see your doctor.


Adult assembly required

- It is recommended to assemble the product by two adults.
- Due to its weight and size, the product should be assembled in the location where it will be used. Make sure that there is enough clearance to walk around the product as you assemble it.
- Use gloves to protect your hands from pinch points during assembly.
- We've provided tools to help with assembly, but you're more than welcome to use your own tools.

• one Phillips screwdriver



• Socket set













• Adjustable wrenches






• Electric Wrench

Parts List

Bottom Frame  ① X1	Swing Frame  ② X1	Lower Stand  ③ X1
Inner Tube of Stand  ④ X1	Lower Adjustment Bracket  ⑤ X1	Upper adjustment bracket  ⑥ X1
Foam  ⑦ X2	Counterweight Outer Tube  ⑧ X1	Knob  ⑨ X3
Foam Cover  ⑩ X2	Buffer Ring  ⑪ X1	Spring Clip  ⑫ X1



Hardware List


No.	Code	Diagram	Description	Quantity	Spare
1	B1		Bolt M8x20mm	3	
2	B2		Bolt M10x25mm	1	
3	B3		Bolt M10x70mm	4	
4	C1		M10 Washer	7	2
5	D1		M10 Nut	3	
6	*		Wrench	1	
			S6x96mm	1	
			S5x85mm	1	

THE SPARE BAG INCLUDED EXTRA HARDWARE FOR DAMAGED OR MISSING SMALL HARDWARE WHILE YOU ARE ASSEMBLING


Assemble

Step 1

							
Bolt M10*70mm		M10 Washer		M10 Nut			
B3	3PCS	C1	5PCS	D1	2PCS		



 Note: Pay attention to the direction of the nut.



Note: The two holes recommended for connection.
According to the mating product, the front and back can be adjusted.


Assemble

Step 2

 Bolt M8*20mm								 S5	
B1	1PC								




The notch and the nut are on the same side.



Assemble


Step 3



Assemble

Step 4



 Bolt M8*20mm								 S5
B1	1PC							




 The notch faces downward.

Assemble

Step 5

 Bolt M10*70mm		 M10 Washer		 M10 Nut		 S6	
B3	1PC	C1	2PCS	D1	1PC		




Assemble




Step 6

 Bolt M8*20mm								 S5	
B1	1PC								

! The notch faces outward.





! The large hole faces upward.



Assemble


Step 7

 Bolt M10*25mm								 S6
B2	1PC							



Assemble

Step 8



CHECK THAT ALL BOLTS ARE TIGHTENED.